



TRUFIG

212 Avenida Fabricante
San Clemente, CA 92672
(949) 492 - 7777

TRUFIG and the TRUFIG Logo are
trademarks of Dana Innovations.
© 2016 Dana Innovations.
All rights reserved.

APPLICATION NOTE

#G-12

Universal IG Trim Component Shim Matrix and Selection Guide

Overview:

This guide is to help you select the correct shims for a IG universal trim component. Look for your device in the shim matrix below. If you cannot find it, proceed to the shim selection guide.

Shim Matrix:

Device	Fascia	Insert	.020	.030	.040	.063
Leviton IG Receptacle 5325 & T-5325	IG Receptacle	✓	-	-	-	-
Leviton Quickport Decora Insert	Data Jack	✓	-	-	-	-
Lutron SeeTouch QS Keypad	QS Cutout	-	-	-	-	-
Lutron SeeTouch Keypad	ST Cutout	-	-	-	-	-
Lutron QS Decora Insert	Decora	-	✓	-	-	-
Leviton GFCI Receptacle 7599	Decora	-	✓	-	-	✓

Shim Selection Guide for Unlisted Devices With Decora Fascia:

Step 1: Locate all the components necessary. (device, shims, fascia, and trim component)

Step 2: Install the device into the subplate.

Step 3: Notice the level difference between the fascia and the device face.

Step 4: To determine what shims to use; stack a shim or a combination of shims next to the device until they're flush with the device face. Then install the shims between the trim component and the device.

